

# UV Lighted Bollard Cover Installation Instructions

## What You Will Receive:

- Designated number of Bollard Covers
- Two pieces of neoprene tape for each Bollard Cover

## Installation Instructions:

### Step #1

- Remove the back of the first adhesive tape strip
- Wrap it firmly around the top of the post, approximately 6" from the top
- Make sure to leave a 1" gap between the ends of the tape to allow airflow while installing the cover



### Step #2

- Remove the back of the second adhesive tape strip
- Wrap it firmly around the bottom of the post, approximately 6" from the bottom
- Do not leave a 1" gap this time around, make sure ends of tape connect

### Step #3

- With the tape in place, slowly slide the Ideal Shield Bollard Cover over the post.
- If the tape is applied correctly, you will hear air being forced out while sliding it down the post, creating a vacuum seal.
- The Ideal Shield Bollard Cover is now secure over the pipe.



### Step #4

- Remove protective bubble wrap and protective tape over solar panel before use

**TRAFFIC SAFETY WAREHOUSE**  
The Best in Safety for Less

[TrafficSafetyWarehouse.com](http://TrafficSafetyWarehouse.com)

(847) 966-1018